



PERSPECTIVE
DRAINAGE INLET MARKER
(MEDALLION) ON DRAINAGE INLET
INSTALLATION LOCATIONS

INSTALLATION INSTRUCTIONS

1. TAKE CORE DRILL (4") AND SCORE CONCRETE 1/8 - 1/4 INCH. (GENERATOR REQUIRED FOR POWER). USE WATER SPRAYER TO ASSIST CONCRETE CUTTING.
2. PLACE MEDALLION INTO GROOVE.
3. TAKE HAND DRILL WITH 1/4 IN. DRILL BIT AND DRILL TO 3/4 IN. DEPTH.
4. PLACE RIVET INTO HOLE OF MEDALLION.
5. TAKE A 2-3 POUND HAND HELD MALLET AND DRIVE RIVET INTO HOLE.

DRAINAGE INLET MARKERS

NO SCALE

NO.	REVISIONS	DATE	BY

DWG: D28.DWG



Department of
 Public Works
CLARK COUNTY
 WASHINGTON
 proud past, promising future

DRAINAGE INLET MEDALLION DETAIL

[Signature]
 APPROVED
 COUNTY ENGINEER

01/07/16
 DATE

STANDARD
D28
 DETAIL
 DESIGNED
 DRAWN
 DATE 12/22/15